Van Drivers DAILY WALK AROUND CHECKS

Tow bars & tail lift

Check that:

- tow bar is secure and any trailer is correctly and securely attached with all electrical connections working correctly
- tail lift is secure and free from damage, functions correctly and the electrics are working correctly

Security of Body/Wings

Check that:

- all fastening devices are present, complete, secure and in working order
- all cab and vehicle doors are secure when closed
- no body panels or parts are loose and in danger of falling off

•••••

there are no sharp edges or damage

Tyres and wheel fixing

Check as much of each tyre/wheel as you can see. There must be:

- minimum tread depth of 1.6mm for vehicles up to 3.5 tonnes and 1mm for those over 3.5 tonnes
- sufficient inflation of each tyre
- no deep cuts or bulges in the sidewall
- no cord visible anywhere on tyre
- no missing or insecure wheel nuts

Wings and Mudflaps

Check that these are:

- fitted (where required)
- rigid and secure
- undamaged
- not clogged with mud or debris

Security of load

Check that:

- any load is secured adequately
- van doors have an effective

Ò

locking device

Excessive engine exhaust smoke

Check that:

the exhaust does not emit excessive amounts of smoke

.

Reflectors

Check they are not:

- obscured
- missing
- broken
- of the wrong colour

••••••

Fuel/Oil leaks

Check that:

- the fuel filler cap is properly located
- brake fuid, engine coolant, engine oil, power steering fluid, windscreen washer fluid and water levels are correct

With engine on check that:

- underneath vehicle for any leaks of fuel/oil
- if leaks are detected that are not fuel or oil, trace the cause (ie power steering fluid, water etc)

nent is to provide a concise set of guidelines that cover the majority of operational scenarios. For a strict interpretation of the regulations please refi

.

river Require Ltd waives all liability for any costs, damages or any other consequences resulting from the application or interpretation of the contents of this docume © 2016 Driver Require Group Limited. All rights reserved

red Office - 1st Floor Niall House, 24-26 Boulton Road, Stevenage, Hertfordshire, SG1 4QX. Registered in England and Wales - Company NO: 04312493



DRIVER REQUIRE

www.driverrequire.co.uk 0345 222 21 21

Check that the unit works correctly when control is operated

Steering

Check steering for excessive play When checking for leaks underneath vehicle, visually check the major steering compoents to ensure that they are present, secure and undamaged

the service brake operates and does not have excessive travel the parking brake is operational and does not have excessive travel the service brake pedal does not have excessive sideplay or missing, loose or incomplete anti-slip provisions

•

Windscreen wipers & washers

Check that:

- wipers work correctly when switched on and cover the full swept area of the screen
- wiper blades are not so deteriorated that they do not clear the screen effectively when used with washers
- washers point at screen and are operational
- washer fluid is topped up

Lights & indicators

Check that:

- all lights & indicators work correctly
- all lenses are present, clean and of the correct colour
- stop lamps come on when the service brake is applied and go out when released
- marker lights are present and work (where applicable)
- all dashboard warning lamps work correctly including:
- ABS - main beam headlamp - warning lamp
- airbag (SRS) - EPS
 - parking brake warning lamp